

2 Gang 150W Smart Toggle Switch - Traditional




Contents

20-GRD134 2 Gang Circular Hole Grid Plate - Traditional			
	-20-PLT134 2 Gang Circular Hole Traditional Grid Plate		
	-20-EDG008 Double Traditional Type Gasket		
	SGPYLK-34 Double Grid Frame (Yoke)		
SGP315	20A 2 Way & Off Retractive CM-Grid Toggle Switch - Grid Module X 2		
Enkin ZDM150	150W LED Zigbee Module X 2		



20A 2 Way & Off Retractive CM - Grid Toggle Switch Module



TECHNICAL SPECIFICATION

Standard(s)	BS EN 60669-1		
Voltage Rating	20 Amp, 250V~ (20AX – no derating for inductive or fluorescent loads)		
Contact Gap	Mini-gap		
Mounting Box Depth (Min)	35mm		
Terminal Capacity	4x 1.5mm², 2x 2.5mm² & 1x 4.0mm²		
Size	55mm × 25mm × 41.8mm		
Product Class 1	Face plate must be earthed		
Ambient Operating Temperature	-5° to +40°C		
Recommended Location	Internal Use Only		
Maximum Installation Altitude	2000m		
IP Rating	IP2XD		
Switched Poles	Single		
Mains Frequency	50hz - 60hz		
Contact Gap Minimum	3mm		

ZDM150

Ov

Enkin 150W LED Zigbee Module

50mm

Markings & Standard(s)	CE, UKCA, BS EN 60669-2-1		
Zigbee Protocol	3.0		
Operating Voltage	220-240V AC		
Main Frequency			
	2W LED (2W Incandescant / Halogen)		
	150W LED (150W Incandescant / Halogen)		
	Multi way (retractive switch), (2way up/down retractive switch)		
	Trailing edge & leading edge phase control		
Mounting Box Depth (Min)			
	1 x 4mm² / 1 x 2.5mm² / 3 x 1.5mm² / 4 x 1mm²		
	2 x 'C' (live), '1' x L (load), '1' x for one way push retractive switch, '2' x for 2 way retractive switch		
Neutral Required			
Short Circuit Protection			
	Yes - Thermal resettable fuse		
Soft Start			
	Previous state recall		
	Yes, non volatile		
	Yes, non volalle Yes - Following a defined procedure		
	Yes - TE & LE mode change following a defined procedure		
	50mm x 49.5mm x 15.1mm		
Climate Range	 0°C to 40°C, Humidity 0% to 95% non-condensing 		
Recommended Location	Indoor use only		
Maximum Installation Altitude	2000m		
IP Rating	IP2XD		


Operating Voltage		240V ac		
Nominal Operating Freq.		50 Hz		
Dimmir	Dimming Technique Trailing & Leading Edge Phase Control		itrol	
	Compliance	BS EN 60669-2-1		
Load Symbol	Compatible Loads		Max Load	Min Load
-×	Dimmable LED lighting		150W TE 100W LE	2W

Multi-Gang Switch De-Rating Chart			
	Low voltage lighting with electronic transformers	150W TE 100W LE	2W
-Ċ	240V Incandescent & Halogen lamps	150W TE 100W LE	2W
-		TOOTTEE	


1 Gang	2 Gang	3 Gang	4 Gang	5 Gang
150W	127W	105W	82W	60W

WIRING EXAMPLES

ONE-WAY PUSH RETRACTIVE SWITCH WIRING OPTION




TWO-WAY & OFF PUSH RETRACTIVE SWITCH WIRING OPTION



IMORTANT NOTE:

Some driverless products can still operate with a small amout of residual current present, such as LED strip lighting etc, it may be necessary to fit a bypass device to allow this product to dim completely to off.



DIMMER SETUP

NOTE: Manual control of the On/Off function and dimming up and down can also be achieved with a connected Retractive Switch, or multiple (parallel) Retractive Switches. Please refer to example circuit diagrams to the right of this text for some connection examples of this option.

A fast click of the retractive switch will turn the lamp (or Load) on and off, holding the switch will alternately dim the lamp up or down, release the switch when desired lamp brightness has been achieved.

The minimum/maximum level and dimming mode can be manually adjusted by following the procedures below.

SETTING THE MINIMUM LEVEL

- 1. Whilst on, adjust dimmer to your desired minimum brightness.
- 2. Push the rear setup button 3 times within 2 seconds.
- **3.** The LEDs will step up and down in brightness once to confirm the setting has been saved.

SETTING THE MAXIMUM LEVEL

- 1. Whilst on, adjust dimmer to your desired maximum brightness.
- 2. Push the rear setup button 5 times within 3 seconds.
- **3.** The LEDs will step up and down in brightness once to confirm the setting has been saved.

FACTORY RESET FOR MIN/MAX BRIGHTNESS

- 1. Please note this factory reset will reset all the min and max brightness settings.
- 2. Whilst on, push the rear setup button 7 times within 5 seconds.
- **3.** The LEDs will step up and down in brightness three times to confirm that the min/max setting has been cleared.

CHANGING THE DIMMING MODE

The default mode of the dimmer is Trailing Edge, but it can be put into Leading Edge if required. Please ensure that you know the correct mode for your lamp.